



Cleaning polycarbonate diffusers on fittings

Dutch Electro fittings are, in general, equipped with polycarbonate diffusers. These diffusers need to be cleaned in the following order:

- *Dusting*
Dust with a soft, damp cloth or chamois. Dry or gritty cloths may cause surface scratches and create a static electric charge on the surface of the polycarbonate diffusers.
- *Lukewarm cleaning*
Clean polycarbonate diffusers with mild soap and lukewarm water. Use a clean soft cloth, applying only light pressure. Rinse with clean water and dry by blotting with a damp cloth or chamois.
- *Do not apply*
Window cleaning sprays, kitchen scouring compounds or solvents such as acetone, gasoline, alcohol, oils, carbon tetrachloride or lacquer thinner or any substance that is not compatible with these polycarbonate diffusers. These can scratch the surface and / or weaken the products causing small surface cracks called 'crazing'.